


Digital Copier Meter Readings

KM1500/ KM1510/ KM1810/ KM2020

Hold down stop /clear key
3 dashes on Display Screen
Copy Count on Display Screen



KM1815/ KM1820

System Menu
OK
OK
Scroll down to status page
OK
Yes
Total printed pages on bottom
of report

KM 2530/ KM3530/ KM2030


Meter on the right-hand side of the machine above bypass

KM 3035/ KM4035/ KM5035

***KM6030/ KM8030**

Default Setting /Counter key
or

* System Menu /Counter key
Press Counter check on Display
Top right of display
Total Black and White copies





KM3050/ KM4050/ KM5050

Press Counter Key on keyboard
Total Copies in top right corner of display

KM4230/ KM5530

Inside front door

KM2050/ KM2550

Press Printer Key

Scroll to menu

OK

OK

Scroll to Print

OK

Printed pages in Page Information section

Analog Copier Meter Readings

DC 1205 / DC1415 /DC1656

DC1860/ DC2360 /DC2155/

DC3055 /DC3060

Inside front cover, meter

DC1355

Meter in Back Corner

Near Paper Exit

DC1460/DC1470

Down through glass in back right-hand corner

